

Digital Camcorders - Memory/HDD/Digital

Download to Mac								
OS	Mac OS X 10.6							
I/F	USB			USB				
Model	IEEE1394	AVCHD	SD card AVCHD	Card/Movie	Card/Still	Card/Movie	Card/Still	
FS10/11/100	Not supported	Supported	Supported	---	---	---	---	
HF10		Not Supported						
HF100		Supported	Supported *1					
HF11								
HG10		Not Supported						
HG20		Supported	Supported					Supported *1
HG21								
LEGRIA FS20/21/22/200								
LEGRIA HF S10/S100								
LEGRIA HF S11								
LEGRIA HF20/HF200								
LEGRIA HF21								

Digital Camcorders - DVD

Download to Mac								
OS	Mac OS X 10.6							
I/F	USB			USB				
Model	IEEE1394	AVCHD	SD card AVCHD	Card/Movie	Card/Still	Card/Movie	Card/Still	
DC10	Not supported	Supported	Not supported	---	Supported *1	---	Supported	
DC100		Not supported		Not supported	---	---	---	Not supported
DC20		Supported		Supported *1	---	---	Supported	
DC210/211/201								
DC22								
DC230/220								
DC320/310		Not supported		Not supported	Not supported	Not supported	Not supported	Not supported
DC330		Supported		Supported *1	---	Supported		
DC40		Supported		Supported *1	---	Supported		
DC410/411		Not supported		Not supported	Not supported	Not supported	Not supported	Not supported
DC420		Supported		Supported *1	---	---		
DC50/51								
HR10								

Supported Recognized

Supported *1 [Install Rosetta.](#)

Not supported*: CameraWindow does not start

Not supported Not recognized

--- No function

Digital Camcorders - 'mini-DV Tape Professional/Advance Amateur

Download to Mac								
OS	Using iMovie09 DV/HDV movie *	Using iMovie09 DVD Video/AVCHD movie *	Using iMovie09 AVCHD movie *	Using CW	Using standard function of OS (ImageCapture)			
I/F	USB			USB				
Model	IEEE1394	AVCHD	SD card AVCHD	Card/Movie	Card/Still	Card/Movie	Card/Still	
XH A1	Supported	---	---					
XH A1S		---	---					
XH G1		---	---					
XH G1S		---	---					
XL 2		---	---					
XL H1		---	---					
XL H1A		---	---					
XL H1S		---	---					
XL1		---	---					
XL1S		---	---					
XM 2		---	---		Not Supported*	Not Supported*	Supported	Supported
XM1		---	---					

Supported Recognized

Supported *1 [Install Rosetta.](#)

Not supported*: CameraWindow does not start

Not supported Not recognized

--- No function

Digital Camcorders - mini-DV Tape consumer

Download to Mac								
OS	Using iMovie09 DV/HDV movie *	Using iMovie09 DVD Video/AVCHD movie *	Using iMovie09 AVCHD movie *	Using CW	Using standard function of OS (ImageCapture)			
OS	Mac OS X 10.6							
I/F		USB		USB				
Model	IEEE1394	AVCHD	SD card AVCHD	Card/Movie	Card/Still	Card/Movie	Card/Still	
HV10	Supported	---	---		Supported *1		Supported	
HV20		---	---					
HV30		---	---					
MD120/110/111/101		---	---	---	---	---	---	---
MD160/150/140/130		---	---	Supported *1	Supported *1	Supported	Supported	Supported
MD235/225/215/216/205		---	---	---	---	---	---	---
MD255		---	---		Supported *1			Supported
MV1		---	---	---	---	---	---	---
MV10(i)		---	---	---	---	---	---	---
MV100		---	---	---	---	---	---	---
MV20(i)		---	---	---	---	---	---	---
MV200(i)/MV210		---	---	---	---	---	---	---
MV3(i)		---	---	---	---	---	---	---
MV3(i) MC		---	---	---	---	---	---	---
MV30(i)		---	---	---	---	---	---	---
MV300(i)/MV310		---	---	---	---	---	---	---
MV4(i)		---	---	---	---	---	---	---
MV4(i) MC		---	---	---	---	---	---	---
MV400(i)/MV410		---	---	---	---	---	---	---
MV430(i)/ MV425		---	---	---	---	---	---	---
MV450(i)		---	---	---	---	---	---	---
MV5(i)		---	---	---	---	---	---	---
MV500(i)/MV510/MV490		---	---	---	---	---	---	---
MV530i		---	---	---	---	Not supported*	---	Supported
MV550i		---	---	---	---		Not supported	Not supported
MV5iMC		---	---	Not supported	Not supported	Not supported	Not supported	Not supported
MV600(i)		---	---	---	---	---	---	---
MV630i		---	---	Not supported	Not supported	Not supported	Not supported	Not supported
MV650i	---	---	Not supported	Not supported	Not supported	Not supported	Not supported	
MV6iMC	---	---	Supported *1	Supported *1	Supported *1	Supported	Supported	

Supported Recognized

Supported *1 [Install Rosetta.](#)

Not supported*: CameraWindow does not start

Not supported Not recognized

--- No function

Digital Camcorders - mini-DV Tape consumer

Download to Mac								
OS	Using iMovie09 DV/HDV movie *	Using iMovie09 DVD Video/AVCHD movie *	Using iMovie09 AVCHD movie *	Using CW	Using standard function of OS (ImageCapture)			
OS	Mac OS X 10.6							
I/F		USB		USB				
Model	IEEE1394	AVCHD	SD card AVCHD	Card/Movie	Card/Still	Card/Movie	Card/Still	
MV700(i)/MV690	Supported	---	---	---	---	---	---	
MV730i		---	---	Supported *1	Supported *1	Supported	Supported	
MV750i		---	---	---	---	---	---	
MV800(i)/MV790		---	---	---	---	---	---	
MV830(i)		---	---	---	---	---	---	
MV850i		---	---	---	Supported *1	Supported *1	Supported	Supported
MV880X(i)		---	---	---	---	---	---	---
MV920 / MV901 / MV900 / MV890		---	---	---	---	---	---	---
MV940 / MV930		---	---	---	Supported *1	Supported *1	Supported	Supported
MV960 / MV950		---	---	---	---	---	---	---
MVX1(i)		---	---	---	---	---	---	---
MVX100i		---	---	---	Not supported	Not supported	Not supported	Not supported
MVX10i		---	---	---	Supported *1	Supported *1		Supported
MVX150i		---	---	---	Not supported	Not supported	Not supported	Not supported
MVX1S(i)		---	---	---	Supported *1	Supported *1	Supported	Supported
MVX200(i)		---	---	---				
MVX20i		---	---	---	---	---	---	---
MVX250i		---	---	---	---	---	---	---
MVX25i		---	---	---	---	---	---	---
MVX2i		---	---	---	Not supported	Not supported	Not supported	Not supported
MVX300		---	---	---	Supported *1	Supported *1	Supported	Supported
MVX30i		---	---	---			Not Supported	
MVX330i		---	---	---			Supported	
MVX350i		---	---	---			Not Supported	
MVX35i		---	---	---			Not Supported	
MVX3i		---	---	---			Not Supported	
MVX40(i)		---	---	---			Supported	
MVX45i		---	---	---				
MVX460 MVX450 / MVX430	---	---	---					
MVX4i	---	---	---					

Supported Recognized
 Supported *1 [Install Rosetta.](#)
 Not supported*: CameraWindow does not start
 Not supported Not recognized
 --- No function